
ZTE MF971V

APN SETTINGS GUIDE

If you experience issues connecting to the internet you might need to put the specific provider APN settings manually. This is a quick guide how to do this. The APN settings for every provider can be searched online.



1 Connect to the configuration interface of the Mobile Router. A pop-up notification will appear automatically prompting opening of a default browser window with the configuration interface. If it does not happen automatically, the configuration interface can always be reached by typing: 192.168.0.1 into the address bar of a browser.


2 The default password is: **admin.** Click on the "**Login**" button.




3 Click on the top "Mobile Settings" Button. (The bottom button is for the Wi-Fi Settings).

ZTE MF971V

APN SETTINGS GUIDE



4 Click on **"APN"**.



5 Click on "**Add New**" Button.

6 Put in the specific APN settings for your provider.

7 Finish with clicking on the "**Apply**" Button.